



## Uraruuvit, lieriökanta



### Suora-ruuvi DIN 84 ISO 1207

Ø mm	L mm	Sinkitty
M2	6	0040 2 6
	10	0040 2 10
	12	0040 2 12
	16	0040 2 16
	20	0040 2 20
M2,5	6	0040 25 6
	8	0040 25 8
	10	0040 25 10
	20	0040 25 20
	M3	6
8		0040 3 8
10		0040 3 10
12		0040 3 12
16		0040 3 16
20		0040 3 20
25		0040 3 25
30		0040 3 30
35		0040 3 35
40		0040 3 40
50		0040 3 50
M4	4	0040 4 4
	6	0040 4 6
	8	0040 4 8
	10	0040 4 10
	12	0040 4 12
	14	0040 4 14
	16	0040 4 16
	20	0040 4 20
	25	0040 4 25
	30	0040 4 30
	35	0040 4 35
	40	0040 4 40
	45	0040 4 45
	50	0040 4 50
	55	0040 4 55
	60	0040 4 60
	70	0040 4 70
80	0040 4 80	
100	0040 4 100	

Ø mm	L mm	Sinkitty
M5	6	0040 5 6
	8	0040 5 8
	10	0040 5 10
	12	0040 5 12
	16	0040 5 16
	20	0040 5 20
	25	0040 5 25
	30	0040 5 30
	35	0040 5 35
	40	0040 5 40
	45	0040 5 45
	50	0040 5 50
	60	0040 5 60
	70	0040 5 70
	80	0040 5 80
90	0040 5 90	
100	0040 5 100	
M6	8	0040 6 8
	10	0040 6 10
	12	0040 6 12
	16	0040 6 16
	20	0040 6 20
	25	0040 6 25
	30	0040 6 30
	35	0040 6 35
	40	0040 6 40
	45	0040 6 45
	50	0040 6 50
60	0040 6 60	
70	0040 6 70	
80	0040 6 80	
90	0040 6 90	
100	0040 6 100	

### Liitinruuvi Suora-ruuvi DIN 85



Ø mm	L mm	Sinkitty
M5	10	0041 5 10
M6	10	0041 6 10