



Your toast, your way with Explore 7

From defrosting sliced bread to browning bagels, the Explore 7 Toaster delivers accurate results. The adjustable settings give you the power to create your ideal toast. And with additional accessories, you can even warm pastries too.

Product Benefits & Features

Precise results every time, with seven settings

No matter what kind of bread you're warming, the Explore 7 toaster has the perfect setting. Choose from seven different browning options, offering lower powers for soft bakes like brioche, and higher ones for tougher breads like ciabatta. Your toast, your way.

- Bun warmer
- Storage for the cord
- Defrost function
- Reheat function
- Stop button


Defrost or reheat at the push of a button

Bring bakery freshness back to your breads with the Explore 7's reheat setting. The programme will gently warm breads through without re-toasting them. And for loaves and slices that have been preserved in the freezer, the defrost setting will quickly revive them to your exact taste.


Warming rack and anti-dust lid accessories

Gently heat pastries and croissants with the included warming rack. The handy accessory is placed on top of the toaster, offering an easy way to evenly warm breads that are too large for the toaster. While the plastic lid will keep dust out when the toaster's not in use.

Precise results with lift-and-look feature

Avoid under or over-cooking toast with the lift-and-check function. The lever-operated system lets you take a peek at your toast without disturbing the cycle. Letting you achieve the perfect result every time, without the guesswork.

Effortless cleaning, with crumb tray

The built-in crumb tray is designed to catch every crumb, meaning there's no need to upturn the toaster when it's time for a quick clean. The plate is easy to eject and empty, saving time on maintenance and other cleaning duties.

Product Specification	
Brand	Electrolux
Main colour	Black Pearl
Accent colour	Copper
Product Class	Electrical Cooking
Product Typology	Toaster
Defrost button	Yes - with pilot light
Cord length external	0.75
Cord storage	Yes
Power W	980
Voltage	220-240
Width mm	183.2
Depth mm	200.5
Height total	314.2
Product Number Code	910 003 578
Bar code	7332543723867