Essentia Intelligent Twin Switch Monitor

EME211-I

Instruction Sheet

R10127GB2

Schneider Electric
www.se.com/buildings

R10127GB2
October 2023

© 2018-2023 – Schneider Electric. All Rights Reserved. This information is only to be used as guidance. Subject to changes and errors.

Contents

Safety Information 4

Related Information 4

1 Essentia Intelligent Twin Switch Monitor EME211-I 4

1.1 Status indications 4

1.2 Dimensions 5

1.3 Essentia Intelligent Twin Switch Monitor standard resistive monitoring mode connectivity diagram 5

Safety Information

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Related Information

For technical specifications, please refer to the Product Datasheet for FFS06720317 on se.com.

1 Essentia Intelligent Twin Switch Monitor EME211-I

The Essentia intelligent twin switch monitor EME211-I (FFS06720317) with isolator provides the function of two switch monitor units within one enclosure. Both units provide supervision of normally open contacts connected to a single pair of cables. The two units are electrically independent of each other. There is a DIL switch on each unit to set the address. Address range is 1-126.

1.1 Status indications

Legend	LED Status	Description
RLY	Continuous Red	Relay Active
RLY	Continuous Yellow	Relay Fault
Poll/ISO	Flashing Green	Polling LED
Poll/ISO	Continuous Yellow	Isolator LED
I/P	Continuous Yellow	Input Fault
I/P	Continuous Red	Input Active

1.2 Dimensions



1.3 Essentia Intelligent Twin Switch Monitor standard resistive monitoring mode connectivity diagram